

Product Information

TEGO® Addibit F 4 HB

PRODUCT DESCRIPTION

TEGO® Addibit F 4 HB is a flaky material based on fatty acid amid.

Typical Properties

Property	Unit	Value
Acid Value	mg KOH/g	28-32
Amine Value	mg KOH/g	130
Appearance		Flaky, yellowish
Melting Point	°C	55

The data represents typical values (no product specification)

TYPICAL APPLICATIONS

- As adhesion promoter in hot-mix asphalt
- In hot-poured asphalt, mastic asphalt, sealing compounds
- As dispersing additive in modified bitumen (e. g. for SMA, roofing applications)
- As emulsifier for the production of cationic bitumen emulsions

BENEFITS & ADVANTAGES

Compared to other products in the market TEGO® Addibit F 4 HB shows outstanding good heatstability.

- Application as bonding and wetting additive
- Enhance wetting and adhesion of acidic silicate aggregate, even on wet surfaces
- Improves the wheel tracking resistance of concrete asphalt up to 50 %
- Heat stable at 200 °C for several days
- Heat stable at 280 °C for several hours
- Improve flow and levelling properties
- Application as emulsifier for rapid setting cationic emulsions
- Good emulsion stability even with more critical bitumen grades

HANDLING & PROCESSING

Application as bonding and wetting additive 0.2 - 0.3 % for use in hot-mix asphalt referred to binder.

Since TEGO® Addibit F 4 HB is a flaky material it may be added to the binder directly without melting.

Application as emulsifier for CRS emulsions 0.2 - 0.3 % for the formulation of CRS emulsions.

Remark: regarding melting point 55 °C of F 4 HB water temperature should be 60 °C.

PACKAGING

Cardboard box with PE inliner à 25 kg

SHELF LIFE

TEGO® Addibit F 4 HB can be stored in closed polyethylene bags for min. 1 year. During transport and storage temperatures above 30 °C the material may become lumpy. However, the performance of the product is not impaired.

HAZARDOUS SUBSTANCE

Information concerning

- Classification and labelling according to regulations for transport and for dangerous substances
- Protective measures for storage and handling
- Measures in case of accidents and fire
- Toxicity and ecological effects

is given in our material safety data sheets.

REGISTRATION LISTING SUMMARY

The relevant components of TEGO® ADDIBIT F 4 HB are listed/registered or exempt in the following chemical inventories:

Registration Listings

Registry	Status
----------	--------

Australia (AICIS)	Yes
-------------------	-----

Canada (DSL)	Yes
--------------	-----

China (IECSC)	Yes
---------------	-----

European Union (EINECS/ELINCS)	Yes
--------------------------------	-----

Registration Listings

Registry	Status
----------	--------

New Zealand (NZIoC)	Yes
---------------------	-----

United States of America (TSCA)	Yes
---------------------------------	-----

Disclaimer

This information and all further technical advice are based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third-party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

Evonik Operations GmbH

Interface & Performance
Goldschmidtstraße 100
45127 Essen, Germany
Phone Europe +49 201 173-2665
Phone Asia +86 21 61191 125
Phone Americas +1 804 727 0700
interface-performance@evonik.com
evonik.click/interface-performance