




DESCRIPTION

TEGO® Wet 510 is a silicone-free substrate wetting additive with good substrate wetting properties. It is highly recommended for waterborne coatings with dynamic applications.

KEY BENEFITS

- contributes to leveling and gloss
- low foaming
- good reduction of dynamic surface tension

EFFECT**Substrate wetting****Anti-crater effect****Flow promotion****Defoaming****Reduction of static surface tension****Reduction of dynamic surface tension****SUITABILITY****waterborne****solventborne****2-pack 100%****radiation-curing****pigmented coatings****clear coatings**

● not suitable ● partly suitable ● suitable

TYPICAL APPLICATIONS

- Car OEM coatings
- Transportation coatings
- Wood coatings
- Printing Inks

TECHNICAL DATA

active matter content	100 %
appearance	clear liquid
chemical description	non-ionic organic surfactant

SOLUBILITY

Water	Ethanol
●	●
TPGDA	Acetone
●	●
Butylacetate	Mineral Spirits
●	●

● not soluble ● partly soluble ● soluble

RECOMMENDED ADDITION LEVEL

As supplied calculated on total formulation: 0.1 - 1.0 %

PROCESSING INSTRUCTIONS

Addition as supplied is recommended.

HANDLING & STORAGE

When stored in an original unopened package between -40 and +40 °C, the product has a shelf life of at least 72 months from the date of manufacture.

This information and all further technical advice are based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

Evonik Operations GmbH | Goldschmidtstraße 100, 45127 Essen, Germany | Telefon +49 201 173-2222 Telefax +49 201 173-1939 | www.coating-additives.com