

TEGO® Foamex 2

DESCRIPTION

TEGO® Foamex 2 is a cost-effective emulsion defoamer based on hydrocarbon compounds combining good defoaming and compatibility for water-based paints. TEGO® Foamex 2 is silicone-free and silica-free.

KEY BENEFITS

- good initial defoaming performances combined with long term stability
- outstanding compatibility
- easy incorporation

APPLICATION RECOMMENDATION

Brush application/roller application



Airless spraying



Compressed air spraying



Flexo/gravure printing



Dip coating, flow coating, curtain coating



Flooring



SUITABILITY

waterborne	solventborne
●	●
2-pack 100%	radiation-curing
●	●
addition to the grinding stage	addition to the let-down stage
●	●
● not suitable ● partly suitable ● suitable	

TYPICAL APPLICATIONS

Architectural paints

TECHNICAL DATA

active matter content	15 %
appearance	white liquid
chemical description	aqueous emulsion of oils and polymers
solvent	water

SOLUBILITY

For stability reasons emulsions may not be diluted by organic solvents.

RECOMMENDED ADDITION LEVEL

As supplied calculated on total formulation: 0.1 - 1.0 %

PROCESSING INSTRUCTIONS

- Can be introduced in the grind and let-down stage.
- Mix before use under low shear forces.

HANDLING & STORAGE

When stored in an original unopened packaging between +4 and +40°C, the product has a shelf life of 12 months from the date of manufacture.

This information and all further technical advice are based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

Evonik Operations GmbH | Goldschmidtstraße 100, 45127 Essen, Germany | Telefon +49 201 173-2222 Telefax +49 201 173-1939 | www.coating-additives.com