

DESCRIPTION

TEGO® Glide 450 provides excellent flow and leveling combined with strong slip properties. It is recoatable and can be used in solvent and waterborne coatings.

KEY BENEFITS

- excellent leveling
- good slip effect
- recoatable

EFFECT**Anti-crater effect****Flow promotion****Slip effect****Anti-blocking****Low foam****SUITABILITY****waterborne****solventborne****2-pack 100%****radiation-curing****pigmented coatings****clear coatings**

● not suitable ● partly suitable ● suitable

TYPICAL APPLICATIONS

- Car OEM coatings
- Car repair coatings
- Wood coatings
- Plastic coatings

TECHNICAL DATA

active matter content	100 %
appearance	clear liquid
chemical description	polyether siloxane copolymer

SOLUBILITY

Water	Ethanol
TPGDA	Acetone
Butylacetate	Mineral Spirits

● not soluble ● partly soluble ● suitable

RECOMMENDED ADDITION LEVEL

As supplied calculated on total formulation: 0.05 - 0.7 %

PROCESSING INSTRUCTIONS

- Addition to the coating as supplied or as a predilution is possible.
- Predilution in a suitable solvent simplifies dosage and incorporation.

HANDLING & STORAGE

- When stored in an original unopened packaging, the product has a shelf life of 60 months from the date of manufacture.
- At low temperatures, reversible turbidity can occur.

This information and all further technical advice are based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

Evonik Operations GmbH | Goldschmidtstraße 100, 45127 Essen, Germany | Telefon +49 201 173-2222 Telefax +49 201 173-1939 | www.coating-additives.com