

## Product Information

## TEGO® Addibit F 4 HB SZ 10

## PRODUCT DESCRIPTION

TEGO® Addibit F 4 HB SZ 10 is a flaky material based on fatty acid amid.

## Typical Properties

Property	Unit	Value
Acid Value	mg KOH/g	8-10
Amine Value	mg KOH/g	155
Appearance		Flaky, yellowish
Melting Point	°C	55

The data represents typical values (no product specification)

## TYPICAL APPLICATIONS

TEGO® Addibit F 4 HB SZ may be used for the production of cationic bitumen emulsions for paving application (CRS-1, CRS-2, and CMS).

## BENEFITS &amp; ADVANTAGES

- Controlled setting properties of the emulsion over a wide range
- Improved wetting and adhesion of acidic silicate chips even on wet aggregate surfaces
- Improved adhesion properties after setting of the emulsion
- Excellent heat stability (200 °C for several days; 280 °C for several hours)

## DOSAGE

- 0.18 - 0.25 % for the formulation of CRS emulsions
- 0.30 - 0.50 % for the formulation of CMS emulsions

## HANDLING &amp; PROCESSING

TEGO® Addibit F 4 HB SZ 10 may also be used for the production of speciality emulsions based e. g. on hydrocar-

bon resins or paraffins (more detailed information is available on request).

TEGO® Addibit F 4 HB SZ 10 is added to the water phase (add to water at 50 to 55 °C which already contains the acid). The required amount of TEGO® Addibit F 4 HB SZ 10 may also be split; i. e. part of it is added to the binder to reduce surface tension to ease the emulsification process.

## PACKAGING

Cardboard box with PE inliner à 25 kg

## SHELF LIFE

TEGO® Addibit F 4 HB SZ 10 can be stored in closed polyethylene bags for min. 1 year. During transport and storage temperatures above 30 °C the material may become lumpy. However, the performance of the product is not impaired.

## HAZARDOUS SUBSTANCE

Information concerning

- Classification and labelling according to regulations for transport and for dangerous substances
- Protective measures for storage and handling
- Measures in case of accidents and fire
- Toxicity and ecological effects

is given in our material safety data sheets.

## REGISTRATION LISTING SUMMARY

The relevant components of TEGO® ADDIBIT F 4 HB SZ 10 are listed/registered or exempt in the following chemical inventories:

## Registration Listings

Registry	Status
Australia (AIIC)	Yes
Canada (DSL)	Yes
China (IECSC)	Yes
EU (EINECS/ELINCS)	Yes

#### Registration Listings

Registry	Status
----------	--------

New Zealand (NZIoC)	Yes
---------------------	-----

#### Registration Listings

Registry	Status
----------	--------

USA (TSCA)	Yes
------------	-----

#### Disclaimer

This information and all further technical advice are based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third-party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

#### Evonik Operations GmbH

Interface & Performance  
Goldschmidtstraße 100  
45127 Essen, Germany  
Phone Europe +49 201 173-2665  
Phone Asia +86 21 61191 125  
Phone Americas +1 804 727 0700  
interface-performance@evonik.com  
[evonik.click/interface-performance](https://www.evonik.com/interface-performance)